


Hydaburg, SE02-01

Center of map at 55° 12.23' N Lat., 132° 49.81' W Lon.



This is not intended for navigational use.

Geographic Response Strategies for Southeast Alaska Subarea, Zone 2



EX01c viewed from the northeast.



EX01a viewed from the west.



DF02 viewed from the north.

Legend Map

- Free-oil Recovery
- Exclusion Booming
- Deflection Booming
- Protected-water Boom
- Staging Area
- Bears in Area, Guards Recommended

ID	Location and Description	Response Strategy	Implementation	Response Resources	Staging Area	Site Access	Resources Protected	Special Considerations
SE02-01-01 	Hydaburg Hydaburg Creek a. Lat. 55° 12.34'N Lon. 132°49.64'W b. Lat. 55° 12.20'N Lon. 132°49.20'W Saltery Creek c. Lat. 55° 11.66'N Lon. 132°47.61'W	Exclusion Exclude oil from entering the identified streams.	Deploy anchors and boom with skiffs (class 6). Place protected-water boom in a chevron pattern in front of the entrance to designated creeks/rivers. Tend throughout the tide. <u>Boom Lengths:</u> a. 200 ft. b. 200 ft. c. 300 ft.	Deployment Equipment 700 ft. protected-water boom 7 ea. anchor systems 20 ea. anchor stakes Vessels 1 ea. class 6 Personnel/Shift 2 ea. vessel crew Tending Vessels 1 ea. class 6 Personnel/Shift 2 ea. vessel crew	Hydaburg	Sites are road accessible. Chart 17407	Fish: chum, coho, pink, dolly varden Habitat: gravel beaches, sheltered tidal flats, marsh Human Uses: commercial fishing, high recreational area,	Vessel master should have local knowledge. Bears are present in the area. Bear guard required. Consult with Incident Command to ensure ADFG-Title 16 and ADNR-Title 41 permits have been obtained. Consult the Site Selection Matrix for cultural resources designation. Consult the ADEC "Spill Tactics for Alaska Responders" manual for additional information on the deployment of these tactics.
SE02-01-02 	Saltery Point Lat. 55° 10.93' N Lon. 132°48.07' W	Deflection Deflect oil coming towards the Saltery Creek tidal flats and into the channel for free-oil recovery.	Deploy boom and anchor system with skiffs (class 6). Position 600 ft. of protected-water boom at a proper angle to deflect oil from Saltery Creek Tend throughout the tide.	Deployment Equipment 600 ft. protected-water boom 3 ea. anchor systems Vessels/Personnel/Shift Same as SE02-01-01 Tending Vessels/Personnel/Shift Same as SE02-01-01	Saltery Point	Sites are road accessible. Chart 17407	Same as SE02-01-01	Vessel master should have local knowledge. Site surveyed: May 31, 2013 Tested: not yet
SE02-01-03 	Hydaburg Nearshore waters in the general area of: Lat. 55° 11.081'N Lon. 131°39.11'W	Free-oil Recovery Maximize free-oil recovery in the offshore & nearshore environment of Hydaburg depending on spill location and trajectory.	Deploy free-oil recovery strike teams upwind and up current of Hydaburg areas. Use aerial surveillance to locate incoming slicks.	Deploy multiple free-oil recovery strike teams as required to maximize interception of oil before it impacts sensitive areas.	Hydaburg	Via marine waters Chart 17407	Same as SE02-01-01	Vessel master should have local knowledge. Use extreme caution, shoal waters with numerous reefs and rocks, shallow mud flats and channels.

NOTE: Sensitive resource information can be found on other maps which can be accessed through the sensitive area section of the SE AK Sub-Area Contingency Plan: http://www.dec.state.ak.us/spar/perp/plans/scp_se.htm.