


# Port Snettisham, SE07-07

Center of map at 57° 59.39' N Lat., 133° 48.57' W Lon.

## Geographic Response Strategies for Southeast Alaska Subarea, Zone 7



This is not intended for navigational use.



EX01a viewed from the northwest.



EX01d viewed from the southwest.

**Map Legend**

-  Free-oil Recovery
-  Deflection Booming
-  Exclusion Booming
-  Protected-water Boom
-  Bears in Area, Guards Recommended

ID	Location and Description	Response Strategy	Implementation	Response Resources	Staging Area	Site Access	Resources Protected	Special Considerations
SE07-07-01 <b>EX</b>	<b>Port Snettisham</b> a. Lat. 57° 57.72'N Lon. 133°49.97'W b. Lat. 58° 01.95'N Lon. 133°48.58'W c. Lat. 58° 02.85'N Lon. 133°48.52'W d. Lat. 58° 01.28'N Lon. 133°44.55'W e. Lat. 58° 00.97'N Lon. 133°43.97'W f. Lat. 58° 00.81'N Lon. 133°43.73'W	<b>Exclusion</b> Exclude oil from entering the salmon bearing creeks in Port Snettisham.	Deploy anchors and boom with skiffs (class 6).  Place protected-water boom in a chevron pattern in front of the entrance to designated creeks/rivers.  Tend throughout the tide.  <u>Boom Lengths:</u> a. 500 ft. b. 300 ft. c. 550 ft. d. 200 ft. e. 200 ft. f. 200 ft.	<b>Deployment Equipment</b> 1950 ft. protected-water boom 12 ea. anchor systems 24 ea. anchor stakes <b>Vessels</b> 1 ea. class 3 2 ea. class 6 <b>Personnel/Shift</b> 7 ea. vessel crew <b>Tending Vessels</b> 2 ea. class 6 1 ea. class 3 <b>Personnel/Shift</b> 7 ea. vessel crew	Vessel Platform	Via marine waters  Chart 17313	Fish: coho, chum, pink, sockeye, dolly varden  Birds: Seabird nesting  Habitat: sheltered rocky shores, gravel beaches  Human Use: High recreation use, commercial fishing	Vessel master should have local knowledge.  Consult with Incident Command to ensure ADFG-Title 16 and ADNR-Title 41 permits have been obtained.  Consult the Site Selection Matrix for cultural resources designation.  Consult the ADEC "Spill Tactics for Alaska Responders" manual for additional information on the deployment of these tactics.  Survey: not yet  Tested: not yet  Bears are in the area. Bear guard required
SE07-07-02 <b>DF</b>	<b>Port Snettisham</b> Lat. 57° 58.59 N Lon. 133°49.51 W	<b>Deflection</b> Deflect oil coming towards Port Snettisham into the channel for free-oil recovery.  If natural deflection is sufficient for Free-oil Recovery, deployment is not necessary.	Deploy boom and anchor system with skiffs (class 6).  Position in a cascaded fashion 3 x 300 ft. of protected-water boom at a proper angle to deflect oil from affection Port Shettisham  Tend throughout the tide.	<b>Deployment Equipment</b> 900 ft. protected-water boom 6 ea. anchor systems <b>Vessels/Personnel/Shift</b> Same as SE07-07-01 <b>Tending Vessels/Personnel/Shift</b> Same as SE07-07-01	Vessel Platform	Via marine waters  Chart 17313	Same as SE07-07-01	Vessel master should have local knowledge.
SE07-07-03 <b>FO-S</b>	<b>Port Snettisham</b> Nearshore waters in the general area of:  Lat. 57° 58.59'N Lon. 133°49.34'W	<b>Free-oil Recovery</b> Maximize free-oil recovery in the offshore & nearshore environment of Port Snettisham depending on spill location and trajectory.	Deploy free-oil recovery strike teams upwind and up current of Port Snettisham.  Use aerial surveillance to locate incoming slicks.	Deploy multiple free-oil recovery strike teams as required to maximize interception of oil before it impacts sensitive areas.	Juneau- 32 nm-via marine waters	Via marine waters  Chart 17313	Same as SE07-07-01	Vessel master should have local knowledge.  Use extreme caution, shoal waters with numerous reefs and rocks, shallow mud flats and channels.