


An example of the *Deflection Booming, Live Tactic*. Actual deployment should be adjusted for local conditions.



An example of the *Free-oil Recovery Tactic*. Actual deployment should be adjusted for local conditions.

Map Legend


-  Free-oil Recovery
-  Deflection Booming, Live
-  Protected-water Boom

Aerial photography of this area is unavailable at this time, but may be included as it becomes available.

Geographic Response Strategies for Western Alaska Subarea, Island Zone

Hall Island, WAK-102

Center of map at 60° 40.76' N Lat., 173° 02.16' W Lon.



This is not intended for navigational use.

ID	Location and Description	Response Strategy	Implementation	Response Resources	Staging Area	Site Access	Resources Protected (months)	Special Considerations
I-02-01 	Hall Island Lat. 60° 39.36'N Lon. 173°07.36'W	Deflection-Live Deflect oil that is going to impact the haul outs and rookery on Hall Island away from the area and into the channel for free oil collection.	Deploy anchors and boom with skiffs (class 6). Use aerial surveillance to identify the incoming oil and its direction. At each location determined by the survey, hold in place with vessels the 3 sections of 300 ft. protected-water boom in a cascaded pattern in the path of the incoming oil. Deflect incoming oil out for free oil collection. Tend throughout the tide.	Deployment Equipment 900 ft. protected-water boom Vessels 6 ea. class 3 Personnel/Shift 18 ea. vessel crew/general techs Tending Vessels 6 ea. class 3 Personnel/Shift 18 ea. vessel crew/general techs	Vessel Platform	Via marine waters Chart 16006c	Marine mammals-walrus, seals, sealions Birds-waterfowl, seabird and shorebird nesting Habitat- exposed rocky shore	Vessel master should have local knowledge. Consult with the National Marine Fisheries Service prior to implementing this tactic. Surveyed: not yet Tested: not yet
I-02-02 	Hall Island Nearshore waters in the general area of: Lat. 59° 51.47'N Lon. 164°19.61'W	Free-oil Recovery Maximize free-oil recovery in the offshore & nearshore environment of Hall Island depending on spill location and trajectory.	Deploy free-oil recovery strike teams upwind and up current of the Hall Island. Use aerial surveillance to locate incoming slicks.	Deploy multiple free-oil recovery strike teams as required to maximize interception of oil before it impacts sensitive areas.	Vessel Platform	Via marine waters Chart 16006c	Same as I-02-01	Vessel master should have local knowledge. Use extreme caution, shallow waters with shifting channels and bars.

NOTE: Sensitive resource information can be found on other maps which can be accessed through the sensitive area section of the Western Alaska Subarea Contingency Plan: http://dec.alaska.gov/spar/perp/plans/scp_wak.htm.